


MEETING OWL PRO (360 DEGREE CAMERA, MICROPHONE AND SPEAKER) INSTRUCTIONS BRUSQUE CONFERENCE ROOM


1. There should be one “control” computer in the conference room, placed next to the Owl.
2. Insert USB cord from OWL device into control computer. It works all major web-based video conferencing platforms, and in-room systems that connect via USB.
3. Launch your video conference platform. Select the Owl Pro as your camera, speaker, and microphone.
4. Audio and video computer settings to eliminate audio feedback, and for optimal performance:

Computers	Audio-in Teams/Zoom, etc. (microphone, top of screen)	Audio (bottom right of screen)	Video
Control computer (meeting leader)	On	On	On
All others in room	Off	Off	Off (unless Owl is not following you appropriately. Then, turn on when speaking.)
All others not in room	On when speaking	On	On

- a. Microsoft Teams example at top of screen: MUTE if in room and not the control computer:



- b. AND mute the audio setting at bottom of screen:



5. **TVs:** There is one TV in the room. The remote is on the table.
6. Range is approximately a 10’ radius for video. Audio is further and works sufficiently in the room.
7. The top view shows a panoramic view of the room. Below that will track the speaking participant(s).



NOTE: Do not move position of the Owl. It is positioned to provide a panoramic view of the room.

Questions? Contact IT Depot Technicians:

Elijah Stigall, estigall@phinia.com

Elaine Sharer, esharer@phinia.com